

B-In-Control

BATCH CONTROLLER



Signal input: pulse, NAMUR or coil flow meter signal

Signal outputs: two control outputs



TABLE OF CONTENTS

1	ABOUT THIS MANUAL.....	4
1.1	How to use this manual	4
1.2	Use of pictograms	4
1.3	Warranty and technical support	4
1.4	Model Reference	4
2	SAFETY	5
2.1	Personal safety	5
2.2	End-user responsibilities	5
2.3	Potential equipment damage	5
2.4	Disposal of electronic waste	5
3	INTRODUCTION.....	6
3.1	System description	6
3.2	Product features	6
3.3	Installation example	7
4	OPERATION.....	8
4.1	Introduction	8
4.1.1	Operating modes	8
4.2	Control panel	8
4.2.1	Display	8
4.3	Batching	9
4.4	Displayed information	10
4.4.1	Totalized flow and accumulated total.....	10
4.4.2	Clear Total	10
4.5	Operator alarms	10
4.5.1	Low battery	10
4.5.2	Alarm ###	10
5	CONFIGURATION.....	11
5.1	Introduction	11
5.2	Configuring using SETUP mode	11
5.2.1	Entering SETUP mode	11
5.2.2	Navigating the SETUP menu	11
5.2.3	Changing configuration settings	12
5.2.4	Returning to Operator Mode	12
5.3	SETUP menu overview	12
5.4	SETUP menu explanations.....	13
	Skip.....	13
	Skip.....	13
5.4.1	Menu 1: Preset	13
5.4.2	Menu 2: Overrun	14
5.4.3	Menu 3: Meter	14
5.4.4	Menu 4: Other	14
6	INSTALLATION.....	15
6.1	Installation / environmental conditions.....	15
6.2	Identification.....	15
6.3	Mechanical installation.....	16
6.3.1	Mechanical dimensions	16
6.3.2	Mounting	17
6.4	Electrical installation	18
6.4.1	Electrical safety.....	18
6.4.2	Sensor supply	18
6.5	Terminal connectors	19
6.5.1	Terminals 1-4: Flow meter input	19
6.5.2	Terminals 5-8: Digital outputs	21
6.5.3	Terminals 9-10: Power supply	21
6.5.4	Service port.....	22
7	MAINTENANCE.....	23
7.1	General directions.....	23
7.2	Instructions for repair	23

7.3	Battery replacement.....	23
7.3.1	Safety instructions	23
7.3.2	Battery replacement procedure	24
7.3.3	Disposal of batteries	24
APPENDIX A - TECHNICAL SPECIFICATION		25
A.1	General	25
A.2	Input.....	26
A.3	Output.....	26
A.4	Operational	26
APPENDIX B - TROUBLESHOOTING		27
APPENDIX C - LEGAL INFORMATION		28
C.1	Declarations of Conformity	28
8	CONFIGURATION SETTINGS LOG	29

1 ABOUT THIS MANUAL

1.1 HOW TO USE THIS MANUAL

This operation manual is divided into two main parts:

- The daily use of the B-In-Control is described in **Section 4: Operation [»8]**. These instructions are meant for users / operators.
- All subsequent sections and appendices are meant for electricians/technicians. These provide a detailed description of all software settings and hardware installation guidance.

Always follow the instructions in this manual, especially the safety information. For additional information, please contact your supplier.

1.2 USE OF PICTOGRAMS

A hazardous situation may occur if the unit is not used for the purpose it was designed for or is used incorrectly. The following pictograms inform you of important information:



A warning indicates a hazardous situation that could cause injury or death.



A caution indicates a condition that could cause:

- moderate/minor personal injury or equipment damage.
- incorrect functioning of the unit or connected instruments.



A note informs you of important information.

1.3 WARRANTY AND TECHNICAL SUPPORT

For warranty and technical support on your Fluidwell products, visit our internet site www.fluidwell.com or contact us at support@fluidwell.com.

1.4 MODEL REFERENCE

Hardware version:	03.32.xx
Software version:	03.06.xx
Document version:	FW_B-IN-CONTROL_M_v2501-01_EN
© Copyright 2025	Fluidwell B.V. - The Netherlands

Information in this document is subject to change without prior notice. The manufacturer is not responsible for mistakes in this material or for incidental damage caused as a direct or indirect result of the delivery, performance or use of this material.

© All rights reserved. No parts of this publication may be reproduced or used in any form or by any means without written permission of your supplier.

2 SAFETY

2.1 PERSONAL SAFETY

- Risk of electric shock: Only open the unit if all leads are free of potential electrical energy.
- Immediately inform the person responsible for the installation if you disagree with the safety precautions or if you detect errors or danger.

2.2 END-USER RESPONSIBILITIES

- Installation, use, and servicing of the unit must be done by trained and authorized technicians.
- This unit is not designed for use in life support appliances, devices, or systems where malfunction of the product could result in personal injury. Customers using or selling these products for use in such applications do so at their own risk and agree to fully indemnify the manufacturer and supplier for any damages resulting from such improper use or sale.
- Check all connections, settings and technical specifications of all peripheral devices supplied with the unit.
- The unit must be installed in accordance with the EMC (Electro Magnetic Compatibility) guidelines.
- The local labor and safety laws, and regulations must be adhered to.
- Modifying the unit without prior written consent from the manufacturer will result in the immediate termination of product liability and warranty period.
- The manufacturer accepts no responsibility whatsoever if the safety information and instructions in this manual are not observed.

2.3 POTENTIAL EQUIPMENT DAMAGE

- Before installing the unit, check the mains voltage and information on the manufacturer's label for product configuration.
- Electro Static Discharge (ESD) causes irreparable damage to electronics. When installing or opening the unit, the technician should first discharge him- or herself by touching a well-grounded object.
- Never touch the electronic components without properly grounded tools.
- Never expose the unit to conditions that may exceed the enclosure classifications as indicated by the manufacturer's label and in the chapter [Section 6.1: Installation / environmental conditions \[»15\]](#).

2.4 DISPOSAL OF ELECTRONIC WASTE



At the end of its life this product should be disposed of according to the (inter)national regulations regarding waste electronic equipment. If a battery is installed in this product, it should be disposed of separately. The separate collection and recycling of your waste equipment will help to conserve natural resources and ensure that it is recycled in a manner that protects the environment.

3 INTRODUCTION

3.1 SYSTEM DESCRIPTION

The batch controller model B-In-Control is a microprocessor-driven instrument designed for batching and filling of small batch sizes up to medium large quantities, as well as showing resettable total and a non-resettable accumulated total.




Fig. 1: The B-In-Control

This manual describes the daily use, configuration and installation of the B-In-Control with pulse input from a flow meter.

The following figure shows the B-In-Control used in a typical installation.




Fig. 2: Typical application

3.2 PRODUCT FEATURES

General characteristics

- User friendliness: easy two button operation

- Good readings in full sunlight and darkness through bright backlight
- Mounting flexibility through compact and durable IP65 enclosure for field, wall or meter mounting
- Ability to process most common pulse signals
- Multiple power supply options, including battery and 10-30 V

Configuration

The B-In-Control can be used for many types of application and has a SETUP mode to allow for configuring it to your requirements. See [Section 5: Configuration \[»11\]](#) for further information.

All settings are stored in an EEPROM memory so they will not be lost if there is a power failure.

Input

- One flow meter with a passive or active pulse, NAMUR or coil signal output
- Several options are available for powering the sensor.

Output

- Two outputs to simultaneously control valves, pumps or other devices.

Backlight

A backlight is standard available (externally powered only).

3.3 INSTALLATION EXAMPLE

Following parts can be recognized in below installation example.




Fig. 3: Installation example B-In-Control

1. Display	3. Label	5. Keys
2. Front cover	4. Back cover	6. Cable entry

4 OPERATION



This product may only be operated by authorized and trained personnel who have read and understood this manual, particularly [Section 2: Safety \[»5\]](#).

4.1 INTRODUCTION

This chapter describes the daily use and operation of the B-In-Control. For this, the B-In-Control is equipped with a control panel that provides the operator with various functions, information and operating modes.

4.1.1 OPERATING MODES

The following operating mode are available:

- **OPERATOR-mode**
This is the default mode of operation and mode indicator **RUN** is shown on the display. This mode is available for all operators and gives access to the other modes. The available functions and rights depend on the type of unit and configured settings. The unit will always return to this mode when there is no user interaction for some time in any of the other modes.
- **SETUP-mode**
This mode allows to review all configuration settings using a SETUP-menu. The mode indicator **SET-UP** is shown on the display and access can be restricted via a password. After selecting a configuration item, it can be changed using the PROGRAM-mode.
- **PROGRAM-mode**
This mode is used to change settings in the SETUP-menu, enter values in OPERATOR-mode or enter a password. When a setting is being changed, this is indicated by the mode indicator **PROG** on the display.

The following paragraphs describe the modes of operation in more detail. SETUP-mode and PROGRAM-mode are described in [Section 5: Configuration \[»11\]](#).

4.2 CONTROL PANEL

The control panel is located on the front side of the B-Series.

- A Liquid Cristal Display (LCD) to show process values and various other information.
- Two keys (START, STOP) to control the unit during operation.

Functions of the keys in Operator Mode



START-key

This key is used to


- Start the batch process
- Enter the preset value during programming
- Reset the total value
- Gain access to the SETUP-mode.



STOP-key

This key is used to

- Stop or interrupt the batch process
- Select total or accumulated total
- Select a digit during programming.



START + STOP keys simultaneously

Press both keys simultaneously to program and save new values or settings.

4.2.1 DISPLAY

In the B-In-Control, all inputs and outputs are continuously processed in the background. The relevant process information is then displayed on a selection of screens when the product is in OPERATOR-mode.

The display contains one line with larger digits and one line with smaller characters below that. The top line displays key process information, while the bottom line usually displays additional information or system messages. Also, measurement unit and symbols to indicate operating mode, function, and status may be displayed.

Normally, the display is updated once per second. By pressing any key, the display switches to refreshing the information 8 times per second. After 30 seconds of key inactivity, the display returns to the standard refresh rate.




Fig. 4: Example of display information in READY state

4.3 BATCHING

Entering a batch quantity

The PRESET value indicates the quantity that will be delivered by the batch process. This value can be changed when the **READY** indicator is shown. To change the PRESET value:

1. Press START and STOP simultaneously. The **PROG** indicator will start flashing.
2. Use the STOP key to select digits and the START key to increase the selected value.
3. Set the new value by pressing START and STOP simultaneously.




Fig. 5: Example display information during programming preset value

When data is changed but START + STOP have not been pressed yet, the changes can be cancelled by waiting for 20 seconds. The previous entered value will be reinstated. The programmed PRESET value will be used for each following batch, until a new value is set.

Starting the batch process

Batching can only be started when the **READY** indicator is shown, by pressing the START key. Then, the actual value is set to zero, the **RUN** indicator is switched on, outputs are switched on and the flow is started. Progress is shown by the increasing actual amount on the top line (large digits), while the target preset amount is shown on the bottom line.



Fig. 6: Example display information during batching process

Interrupting and aborting the batch process

When STOP is pressed once, the batch process will be temporarily interrupted (passed) and the **RUN** indicator will start flashing. The running values are not lost, and batching can be resumed with the START-key.

The process can be ended entirely at all times by pressing STOP twice. The actual delivered quantity is shown and the system returns to steady state. The aborted process cannot be resumed.

Completing the batch process

When the actual value reaches the preset quantity, the outputs are switched off and the batch process is finished.

The exact moment the outputs are switched depends on the configuration settings for overrun (**SETUP 2: OVERRUN**).

- When overrun time is set in **SETUP 2.1: OVERRUN > TIME**, the last measured overrun quantity is taken into account while computing the output switch off moment. The new overrun quantity will be measured. Overrun period will be marked by the flashing **READY** indicator.
- When a pre-close quantity is set in **SETUP 2.2: OVERRUN > PRECLOSE**, the pre-close output (output 2) will be switched off when the batch quantity approaches the preset value. The other output (output 1) will switch off when the full preset quantity is reached.

4.4 DISPLAYED INFORMATION

For displayed information during batching see [Section 4.3: Batching \[»9\]](#). When no batch process is running and the **READY** indicator is shown, the following functions / informations are available.

By pressing the STOP-key, the operator may scroll through a succession of screens showing various process values. The following table shows the available screens.

Selected display	Displayed information
BATCH SCREEN	Actual and preset value
SCREEN 1	Total (possibility to reset Total)
SCREEN 2	Accumulated Total

4.4.1 TOTALIZED FLOW AND ACCUMULATED TOTAL

A resettable Total and non-resettable Accumulated Total are available. Both totalizers count up to 9,999,999 before rolling over to 0. The unit and number of decimals are displayed according to the configuration settings for Total.

4.4.2 CLEAR TOTAL

The value for Total can be cleared and reset to zero. To do so, press START while Total is shown (SCREEN 1). The flashing text "CLEAR – NO YES" is displayed. When START is pressed for a second time, Total is reset to zero. To avoid re-initialization at this stage, press the STOP key or wait for 20 seconds.

Re-initialization of Total DOES NOT influence the Accumulated Total.

4.5 OPERATOR ALARMS

4.5.1 LOW BATTERY

When the battery voltage drops. When the battery voltage becomes too low, the text "LOW bAT" will be displayed, an indication that the operation becomes less reliable. Install a fresh battery as soon as possible when this indication comes on, to keep a reliable operation.

See [Section 7.3: Battery replacement \[»23\]](#) for further information.




Fig. 7: Example of low-battery alarm

4.5.2 ALARM

When "ALARM" is displayed, press SELECT to display the alarm code. Consult [Section B: Troubleshooting \[»27\]](#) for more information.

5 CONFIGURATION

5.1 INTRODUCTION

This chapter describes how technicians can use configuration settings to configure the B-In-Control for optimal functionality. Configuration is done in SETUP mode, using the front keys.

Also, the B-In-Control can be configured by PC with our Remote Configuration Tool. Besides the possibility to configuring the unit, this solution offers up- and download and printing of all settings. The Remote Configuration Tool software package can be downloaded free of charge from our website at www.fluidwell.com/software, and installed on a Microsoft® Windows® PC. The package also contains a quick-start manual with detailed instructions to successfully connect the PC and your B-Series.

Connection between the service port of the B-In-Control and the PC is made by using a special cable (to be ordered separately). For more info see [Section 6.5.4: Service port \[»22\]](#).

5.2 CONFIGURING USING SETUP MODE

For an overview of Operating modes, see [Section 4.1.1: Operating modes \[»8\]](#).



Changing settings may influence current operation

In SETUP mode the unit remains fully operational. Make sure the product is not being used for any application when changing settings.

5.2.1 ENTERING SETUP MODE

1. Press the START-key for 7 seconds. During this, the symbol **SET-UP** will be flashing. You may be prompted to enter a password.
2. The **SET-UP** indicator is now activated on the display and the **RUN** indicator is deactivated.

5.2.2 NAVIGATING THE SETUP MENU

The SETUP menu contains several menu groups, which each contain various menu items. Each menu item has a unique number which is displayed at the bottom of the display. Additionally, each menu item is expressed with a keyword.

The menu number is a combination of two figures separated by a dot:

- the first figure indicates the selected menu group (e.g. 1. TOTAL).
- the second figure indicates the menu item (e.g. 1.1 UNIT).

The following image shows the layout of the menu structure:




Fig. 8: SETUP menu layout and navigation

Navigate the **SETUP** menu with the following functions:



START-key

This key selects the next function in the list (e.g. 1. → 1.1. → 1.2. → 1.... → 1.)
When the top of the list is reached, it will return to the function group selection level.



STOP-key

When only a function group is indicated in the display (one digit), this key scrolls through the function groups (1. → 2. → 3.)

When a function group is entered (two digits in display), this key is used to select the previous function in the list (e.g. 1.2 → 1.1 → 1). When the bottom of the list is reached, it will return to the function group selection.


5.2.3 CHANGING CONFIGURATION SETTINGS

A menu item either contains a value (a number with optionally a decimal point and sign, e.g. -123.45) or a selection list (e.g. L – m³ - USGAL). After a menu item is selected in the SETUP menu, a new value can be programmed by performing the following steps. During the programming sequence, the **PROG** indicator is shown on the display.



When programming new values, changes will only be set after both keys have been pressed simultaneously to confirm the new value (Step 3)!

Step 1: Start the programming sequence



START + STOP

When a menu item is selected in the SETUP menu, pressing both keys simultaneously starts the programming sequence.

Step 2a: Change a value



START

This key is used to increment the selected digit or to select the next position of the decimal point.



STOP

This key is used to select the next digit or to select the previous position of the decimal point.

Step 2b: Change the selection in a list



START


This key is used to select the next item in the list (e.g. L → m³ → USGAL). At the end of the list, the selection will wrap around to the first selection.



STOP

This key is used to select the previous item in the list (e.g. USGAL → m³ → L). At the bottom of the list, the selection will wrap around to the last selection.

Step 3: Finish the programming sequence



START + STOP

During the programming sequence, pressing the keys simultaneously confirms the new value and returns to SETUP mode. To cancel the operation, wait for 20 seconds: the programming sequence is cancelled and the former value is reinstated.

5.2.4 RETURNING TO OPERATOR MODE

When all configuration settings are set correctly, return to OPERATOR mode by pressing the START-key for three seconds, or do not press any key for 2 minutes to return automatically. The **READY** indicator is now activated on the display and the **PROG** indicator is deactivated.

5.3 SETUP MENU OVERVIEW

1	PRESET	DEFAULT
1.1	UNIT	L - m ³ - kg - lb - GAL - USGAL - bbl - no unit
1.2	DECIMALS	0 - 3
1.3	K-FACTOR	0.000010 - 9,999,999
1.4	DECIMALS K-FACTOR	0 - 6

2			OVERRUN	DEFAULT
2.1	TIME	0 - 99		0
2.2	PRECLOSE	0000.000 - 9,999,999		0
3			METER	DEFAULT
3.1	SIGNAL	coil - reed - NPN - PNP - Namur		coil
4			OTHER	DEFAULT
4.1	MODEL	fixed		BASIC61
4.2	SOFTWARE VERSION	fixed		03.06.xx
4.3	SERIAL NUMBER	fixed		xxxxxxx
4.4	PIN	0000 - 9999		0000
4.5	BACKLIGHT	off - on		off

5.4 SETUP MENU EXPLANATIONS

5.4.1 MENU 1: PRESET

Calculating the K-factor



The K-factor is used to convert the flow meter pulse frequency to a quantity. Two examples are given.

Example 1

- The flow meter generates 2.4813 pulses per liter.
- Quantities will be displayed using cubic meters (m³; 1.1: PRESET > UNIT).
- A cubic meter equals 1000 liters, thus the flow meter generates 2,481.3 pulses per m³.
- Enter the K-factor as 248130 at 1.3: PRESET > K-FACTOR and 2 at 1.4: PRESET > DECIMALS K-FACTOR.

Example 2

- The flow meter generates 6.5231 pulses per gallon.
- Quantities will be displayed using gallons (1.1: PRESET > UNIT).
- Enter the K-factor as 652310 at 1.3: PRESET > K-FACTOR and 5 at 1.4: PRESET > DECIMALS K-FACTOR.

1			PRESET
1.1	UNIT	Determines the measurement unit for preset, total and accumulated total. The following units can be selected: L - m ³ - kg - lb - GAL - USGAL - bbl - no unit	
		 NOTE	<i>Changing the measurement unit will have consequences for operator and setup values. Please note that the K-factor should be checked also. Recalculation is not done automatically.</i>
1.2	DECIMALS	Determines for Preset, Total and Accumulated Total the number of digits after the decimal point.	
1.3	K-FACTOR	This value is used to convert the flow meter pulse signals into a total unit. The K-Factor is based on the number of pulses generated by the flow meter per selected measurement unit, as defined in 1.1: PRESET > UNIT.  NOTE <i>Accuracy of the measurement system depends on the accuracy of the K-factor.</i> Examples are given above.	
1.4	DECIMALS K-FACTOR	This setting determines the number of decimals for the K-factor (1.3: PRESET > K-FACTOR). Please note that this setting influences the accuracy of the K-factor indirectly. This setting has NO influence on the displayed number of digits set for Unit (1.1: PRESET > UNIT).	

5.4.2 MENU 2: OVERRUN

Overrun can occur at the end of the batch process, as a result of slowness of a valve / pump. Consequently, the accuracy is less. With this function, the B-In-Control analyses the actual overrun characteristic after every batch. This information is used to correct the overrun automatically. Additionally, output 2 can be used in two-stage batch control to pre-close a valve to avoid e.g. water hammer.

2 OVERRUN		
2.1	TIME	Enter the expected time in the range 0 - 99 seconds, needed by the system to stop a batch. With value 0 the overrun function is disabled. It is advised to provide extra time to avoid an incorrect overrun correction.
2.2	PRECLOSE	For two-stage batch control output 2 can be used to switch off before output 1. The switching moment is based on the remaining quantity to be batched. If set to 0, output 2 will switch simultaneously with output 1.

5.4.3 MENU 3: METER


3 METER						
3.1	SIGNAL	Selects the type of input sensor pickup / signal. The B-In-Control can process several types of input signal.				
	FLOW METER SELECTION CHARACTERISTICS					
		TYPE OF SIGNAL	EXPLANATION	RESISTANCE	FREQ / mV pp	REMARKS
		NPN	NPN input	100 k Ω pull-up	max. 6 kHz	Open collector
		REED	Reed-switch input	1 M Ω pull-up	max. 120 Hz	
		PNP	PNP input	47 k Ω pull-down	max. 6 kHz	
		NAMUR	NAMUR input	820 Ω pull-down	max. 4 kHz	External power required
	COIL	Coil input	-	min. 30 mV pp		

5.4.4 MENU 4: OTHER

4 OTHER		
4.1	MODEL	Provides important information on your product. This information may be required for maintenance or support.
4.2	SOFTWARE VERSION	
4.3	SERIAL NUMBER	
4.4	PIN	All SETUP values can be password protected. A four-digit PIN (password) can be programmed, for example 1234. To disable password protection, enter four zeros (0000).
4.5	BACKLIGHT	Switches backlight on or off. For backlight on, external power is needed.

6 INSTALLATION

6.1 INSTALLATION / ENVIRONMENTAL CONDITIONS



Take the relevant IP classification of the enclosure into account (see identification plate). Even an enclosure rated for IP67 / NEMA Type 4X should NEVER be exposed to strongly varying (weather) conditions.

When used in very cold environment or varying climatic conditions, take the necessary precautions against moisture inside the instrument case.

Mount the B-In-Control onto a solid structure to avoid vibrations.

Relative humidity	< 90% RH
Outdoor use	Suitable for outdoor use
IP and NEMA rating	IP65. NEMA Type 4X
Supply voltage fluctuation	+/- 10% unless stated otherwise
Means of protection	Class II
Over-voltage category	II
Pollution degree	2 (internal environment), 3 (external environment)
Ambient	-20 °C to +60 °C, -4 °F to +140 °F
Altitude	up to 2000 meters (6600 feet)

6.2 IDENTIFICATION

Identification label

To identify your device, all products have a waterproof identification label placed on the outside of the unit.



Fig. 9: Example of external label with general data

Installation label

An installation label is located at the inside of the enclosure, showing additional installation details.




Fig. 10: Example of internal label with installation information

Serial number and year of production

The serial number can be reviewed on the identification label, the installation label, or in **SETUP** 4.3: OTHER > SERIAL NUMBER. The production date is shown on the label and is also indicated by the first 4 digits of the serial number, representing year and week number (YYWW).

6.3 MECHANICAL INSTALLATION

6.3.1 MECHANICAL DIMENSIONS

Enclosure dimensions




Fig. 11: Dimensions

6.3.2 MOUNTING

Wall mounting

The enclosure can be wall mounted with screws using the four available mounting holes. The holes are accessible after removal of the front cover.




Fig. 12: Installation - Wall mount

A: 4x screw / bolt

- Head diameter: 6-8 mm / 0.24"- 0.31"
- Shaft diameter: max. 5 mm / 0.2"
- Shaft length: min. 50 mm / 2"
- Use applicable wall plugs

Note: the rear part may be rotated in 90° steps, enabling cable entry from each direction.

Sensor mounting

The enclosure can be mounted on a sensor by using the mounting hole at the bottom and a lock nut.




Fig. 13: Installation - Sensor mount

6.4 ELECTRICAL INSTALLATION

First consult the table with limiting environmental conditions and safety parameters in [Section 6.1: Installation / environmental conditions \[»15\]](#).



- The installation must comply with (inter)national requirements and local ordinances. Within the United States all field wiring must conform to the National Electrical Code, NFPA 70. Within Canada all field wiring must conform to the Canadian Electrical Code.
- The B-In-Control must be installed in accordance with EMC guidelines (Electro Magnetic Compatibility)



- Electro static discharge can inflict irreparable damage to electronics! Before installing or opening the product, always first discharge yourself by touching a well-grounded object.
- For all wire entries, use cable glands with effective IP65 (or better) seals.
- For opened and unused cable entries, fit blind plugs with effective IP65 (or better) seals.
- Use effective screened cable for input / output signals and provide grounding of its screen to the 'L' terminal (for isolated signals use the corresponding '-' terminal), or at the external device, whichever is appropriate to the application. Do not create ground loops!

6.4.1 ELECTRICAL SAFETY

General remarks

- In case this instrument is connected to a supply by means of a permanent connection, a switch or circuit-breaker shall be included in the installation. This shall be installed in close proximity to the equipment and within easy reach of the operator. It shall be marked as the disconnecting device for the equipment. Furthermore, a protective over-current device with a maximum rating of 0.5 A (e.g. fuse or circuit breaker) must be inserted in the positive supply line.
- The external power supply must be an approved ELV source, insulated from AC mains by double / reinforced insulation per IEC 61010-1. All other inputs and outputs shall at least be reinforced insulated from mains.

6.4.2 SENSOR SUPPLY

Terminal 3: Reference voltage 1.2 – 3.2 V DC

Terminal 3 provides a reference voltage of 3.2 V DC (coil signals 1.2 V) which functions as a limited supply voltage for the signal output of the flow meter.



This voltage may not be used to power the sensor electronics, converters etc., as it will not provide adequate sustained power! All energy used by the flow meter pick-up will directly influence battery life. It is strongly advised to use a zero power pick-up such as a coil or reed switch when operating without external power. It is possible to use some low power NPN or PNP output signals, but battery life will be significantly reduced.

Terminal 4: Sensor supply 8.2 V DC

Terminal 4 offers a supply derived from the supply input (Terminal 10). The output voltage of Terminal 4 is fixed to 8.2 V DC.



The 8.2 V DC sensor supply requires an external supply to be connected. Maximum output current is 10 mA.

6.5 TERMINAL CONNECTORS

The following terminal connectors are available on the B-In-Control.




Fig. 14: Terminal connectors - overview

6.5.1 TERMINALS 1-4: FLOW METER INPUT

Two basic types of flow meter signals can be connected to the unit: pulse or sine wave (coil). The screen of the signal wire must be connected to the common ground terminal (unless earthed at the sensor itself).

The sensor output should match with the selected flow meter input signal at **SETUP Section : SETUP menu overview** [»13]. See **Menu 3: Meter** [»14] for more information.

Sine wave signal (Coil)

The B-In-Control is suitable for use with flow meters with a coil output signal. The minimum sensitivity level is 30 mV pp.




Fig. 15: Terminals 1 - 3: Coil signal input

Pulse signal NPN

The B-In-Control is suitable for use with flow meters with an NPN output signal. For reliable pulse detection, the signal should be above 1.4 V or below 1.0 V under all circumstances. It is advised to use a sensor which is normally open, and is closed only for a short period. In that way, less power will be consumed.




Fig. 16: Terminals 1 - 2: NPN signal input

Pulse signal PNP

The B-In-Control is suitable for use with flow meters with a PNP output signal. 3.0 V DC is offered on terminal 3, which has to be switched by the sensor to terminal 2. Terminal 4 offers a 8.2 V DC when external power is supplied to the unit. For reliable pulse detection, the signal should be above 1.4 V or below 1.0 V under all circumstances. It is advised to use a sensor which is normally open, and is closed only for a short period. In that way, less power will be consumed. For active signals, the maximum voltage is 30 V DC.




Fig. 17: Terminals 1 – 3 or 4: PNP signal input

Reed switch

The B-In-Control is suitable for use with flow meters with a reed switch. The maximum contact resistance of the closed switch is 10 kΩ.




Fig. 18: Terminals 1 - 2: NPN signal input

Namur signal

The B-In-Control is suitable for use with flow meters with a Namur signal. The sensor may be powered via the 8.2 V DC sensor supply at terminal 4, or may be powered externally.




Fig. 19: Terminals 1 – 2 (4): Namur signal input

6.5.2 TERMINALS 5-8: DIGITAL OUTPUTS

The function of the digital outputs is to control a valve, pump or other device.

Two passive transistor outputs are available. Output 1 is used to control the batch process, output 2 will switch simultaneously with output 1 or it can be set for two-stage batch control. The pre-close value is defined with 1: PRESET with a maximum driving capacity of 300 mA @ 30 V DC.




Fig. 20: Terminal connections - Transistor outputs

6.5.3 TERMINALS 9-10: POWER SUPPLY

Connect an external power supply (10-30 V DC) to terminals 9 and 10. Maximum current will be 25 mA. When power is supplied, the internal battery will not be used, and 8.2 V DC sensor supply becomes available at terminal 4. Also, the backlight may be used.

Please note that all common ground terminals are connected inside the B-In-Control.




Fig. 21: Terminals 9-10: Power supply.

6.5.4 SERVICE PORT

A service port enabling configuration of the B-In-Control via an external device such as a laptop is available. Connection to the port should be made with a special communications cable, available through our website or your supplier (accessory ACE02).



The service port is not to be connected permanently




Fig. 22: Terminal connection - Service port

7 MAINTENANCE

7.1 GENERAL DIRECTIONS

The B-In-Control does not require special maintenance unless it is used in low-temperature applications or surroundings with high humidity (above 90% annual mean). It is the users responsibility to take all precautions to dehumidify the B-In-Control in such a way that no condensation will occur, for example by placing a dry silica gel sachet in the casing. For further instructions, please refer to the information which came with your silica gel sachet.

Check periodically

- Condition of casing, cable glands and front panel
- Input/output wiring: reliability and aging
- Process accuracy: because of wear and tear, re-calibration might be indicated
- Battery status indication

Clean the casing with soapy water. Do not use any aggressive solvents.

Battery life

Battery life is influenced by

- Low temperatures - due to battery chemistry available power will be less at low temperatures
- Type of input signal – NPN and PNP consume more power than coil input
- High input frequency.



NOTE

It is strongly advised to use only necessary functions and disable functions not in use.

7.2 INSTRUCTIONS FOR REPAIR

This product cannot be repaired by the user. Repairs may only be done by the manufacturer or its authorized agent.

Repair policy

If you have any problem with your product and wish to have it repaired, please follow this procedure:

1. Obtain a Return Material Authorization (RMA) from your supplier or distributor. Together with the RMA, you need to complete a repair form to submit detailed information about the problem.
2. Send the product, within 30 days after authorization was obtained, to the address provided with the RMA. The RMA number must be indicated on the documents accompanying your physical return.

If the product falls under the warranty conditions, the product will be repaired or exchanged and returned within three weeks. Otherwise, you will receive a repair cost estimate.

7.3 BATTERY REPLACEMENT

Battery specification

Primary, non-rechargeable, Lithium-Metal Thionyl Chloride (Li/SOCl₂), 3.6 V, 2.4 Ah, AA size. (IEC-R6, ANSI size 15).

7.3.1 SAFETY INSTRUCTIONS



WARNING

- Handle the battery with the utmost care to prevent a short circuit and damage. A mistreated battery can become unsafe. Unsafe batteries can cause serious injury.
Do not recharge, crush, disassemble, incinerate, heat above its rated temperature or expose the contents to water.
- Mounting, electrical installation, start-up and maintenance of this device may only be carried out by trained persons authorized by the operator of the facility. Persons must read and understand this manual before carrying out its instructions.

7.3.2 BATTERY REPLACEMENT PROCEDURE

Exchange the battery as follows:

1. Open the B-series. See [Section 6.3: Mechanical installation \[»16\]](#) for more information.
2. Hold the cover (1) and carefully remove the battery (2) from its holder (3). Please note that the holder can be made of plastic (as drawn) or of two metal clips.
3. In case of a plastic battery holder: inspect for signs of damage.
4. Place the new battery in the holder without forcing it. Take note of the polarity!
5. Check that the display comes on.
6. Close the B-series by screwing the front cover back to the back cover.




Fig. 23: Battery replacement procedure

7.3.3 DISPOSAL OF BATTERIES

Dispose of batteries in accordance with the (inter)national, the manufacturer's and the plant owner's standards and regulations.



- Batteries pose an environmental hazard.
- Do not dispose of as general waste or incinerate.
- Return used batteries to a recycling point.

APPENDIX A - TECHNICAL SPECIFICATION

A.1 GENERAL

DISPLAY	
Type	High intensity reflective numeric and alphanumeric LCD with bright backlight, UV-resistant
	<i>Note</i> Backlight not available when battery or loop powered
Digits	7 with height 12 mm (0.47") and 11 with height 7 mm (0.28"). Various symbols and measuring units.
Dimensions	54 x 29 mm (2.13" x 1.14")
Refresh rate	8/s when keys pressed. 30 seconds after last keypress: 1/s.

ENCLOSURE	
Material	GRP (Glass Reinforced Plastic) wall / field mount enclosure with EPDM gasket. UV stabilized and flame retardant material.
Control keys	Industrial type microswitches. UV resistant polyester keypad.
Rating	IP65, NEMA type 4X
Dimensions	92 x 92 x 60 mm (3.62" x 3.62" x 2.36") (W x H x D)
Weight	200 g / 0.44 lbs
Cable entries	Knock-out type 2 x 16 mm / 0.63" 1 x 20 mm / 0.79"
	<i>Note</i> The back cover may be rotated in steps of 90°

OPERATING TEMPERATURE	
Ambient	-20°C to +60°C (-4°F to +140°F)

POWER REQUIREMENTS	
External power supply	10 – 30 V DC. Max power consumption 25 mA.
	<i>Note</i> External power will also supply backlight and 8.2 V DC sensor supply
Battery	Primary, non-rechargeable, lithium metal thionyl chloride (Li/SOCl ₂), 3.6 V / 2.4 Ah. AA size (IEC-R6, ANSI size 15). Life up to 2 years, depending on settings.
	<i>Note</i> Replace battery with identical specification

SENSOR EXCITATION	
Standard	3 V DC reference voltage for pulse signals. 1.2 V DC for coil pick-up. Max 100 µA.
	<i>Note</i> Standard sensor excitation is only suitable for sensors with very low power consumption like coils (sine wave) and reed switches.
With external supply	8.2 V DC, max 10 mA

TERMINAL CONNECTIONS	
Type	Fixed terminal strip. Wire max 1.5 mm ²

DATA PROTECTION	
Type	FRAM backup of all settings. Backup of running totals every minute. Data retention at least 10 years.
Password	Configuration settings can be password protected

DIRECTIVES AND STANDARDS		
EMC	EN/BS 61000-6-2 EN/BS 61326-1	EN/BS 61000-6-3 FCC 47 CFR part 15
RoHS	EN/BS 50581	EN/BS IEC 63000
IP & TYPE	EN/BS 60529	NEMA 250
Note	<i>See the applicable Declaration of Conformity or product certificate for specific revisions and publication dates of applicable standards.</i>	

A.2 INPUT

FLOW METER	
Signal type	Coil / sine wave 30 mVpp, NPN, PNP, reed switch, NAMUR.
Frequency	Max. 6 kHz, but depends on signal type.
K-factor	0.000010 - 9,999,999 with variable decimal position

A.3 OUTPUT

CONTROL OUTPUT	
Function	Batch process one or two stage control output.
Type	Two passive transistor outputs (NPN), not isolated. Max load 300 mA @ 30 V, 25°C

A.4 OPERATIONAL

OPERATOR FUNCTIONS	
Process management	<ul style="list-style-type: none"> • Enter preset value • Start, interrupt and stop batch process
Displayed information	<ul style="list-style-type: none"> • Preset value • Actual batched quantity and preset value • Total • Accumulated total
Reset Total	Total can be reset to zero

(ACCUMULATED) TOTAL, PRESET	
Digits	7 digits
Unit	L - m3 - kg - lb - GAL - USGAL - bbl - no unit
Decimals	0 - 3

APPENDIX B - TROUBLESHOOTING

Table 1 lists and describes how to troubleshoot problems that can occur when installing or operating the B-In-Control.

Table 2 lists internal alarm codes and conditions signaled by a blinking ALARM flag on the display (**ALARM**). Press a key several times to display the 4-digit error code shown in Table 2.

Table 1: Install and configuration errors

Observation	Possible cause	Check
Batched quantity counting too low or too fast	Wrong signal selection in SETUP menu	3.1: METER > SIGNAL
	Unit not matching process	1.1: PRESET > UNIT 1.2: PRESET > DECIMALS
	K-factor setting wrong	1.3: PRESET > K-FACTOR 1.4: PRESET > DECIMALS K-FACTOR
	Sensor power supply not sufficient	Section 6.4.2: Sensor supply [»18]
	Electrical connections wrong	Section 6.5: Terminal connectors [»19]
	Ground loops	Wiring of ground and screening
	Sensor not working properly	Sensor
Batching doesn't stop when complete	Overrun time too long	2.1: OVERRUN > TIME
SETUP- mode unavailable	Password setting	Enter correct password
	Password unknown	Call your supplier

Table 2: Internal alarms

Alarm	Explanation
0001	Display error
0002	Data storage error
0004	Initialization error


When multiple alarms occur, the error code shown is the sum of the error codes as given below. For example 0003 is a combination of error code 0001 and 0002.


An ALARM condition will in most cases be handled internally. If all programmed and measured values appear to be correct, intervention by the Operator is not necessary.

If an ALARM occurs more often or stays active for a longer period, please contact your supplier.

APPENDIX C - LEGAL INFORMATION

C.1 DECLARATIONS OF CONFORMITY

EU Declaration of Conformity		
Fluidwell B–Series indicators		Veghel, February 2022
We, Fluidwell BV, declare under our sole responsibility that the B–Series indicators are designed and will operate conform the following applicable European Directives and Harmonised Standards, when installed and operated according to the related manuals:		
EMC Directive	2014/30/EU	EN 61000–6–2:2005; EN 61000–6–3: 2007 /A1:2011; EN 61326–1:2013
RoHS Directive	2011/65/EU (incl. current amendments)	EN 50581:2012 EN IEC 63000:2018
Last two digits of the year in which the CE marking was affixed: 16.		
I. Meij, Manager Technology		
Fluidwell BV – P.O.Box 6, 5460 AA, Veghel, The Netherlands – Voltaweg 23, 5466 AZ, Veghel, The Netherlands Fluidwell BV is ISO9001 certified by DEKRA Certification BV, Meander 1051, 6825 MJ, Arnhem, The Netherlands.		

UKCA Declaration of Conformity		
Fluidwell B–Series indicators		Veghel, February 2022
We, Fluidwell BV, declare under our sole responsibility that the B–Series indicators are designed and will operate conform the following applicable UK Legislation and Standards, when installed and operated according to the related manuals:		
Electromagnetic Compatibility Regulations 2016		BS 61000–6–2:2005; BS 61000–6–3: 2007 /A1:2011; BS 61326–1:2013
The Restriction of the Use of Certain Hazardous Substances in Electrical and Electronic Equipment Regulations 2012 (incl. current amendments)		BS EN 50581:2012 BS EN IEC 63000:2018
Last two digits of the year in which the UKCA marking was affixed: 22.		
I. Meij, Manager Technology		
Fluidwell BV – P.O.Box 6, 5460 AA, Veghel, The Netherlands – Voltaweg 23, 5466 AZ, Veghel, The Netherlands Fluidwell BV is ISO9001 certified by DEKRA Certification BV, Meander 1051, 6825 MJ, Arnhem, The Netherlands.		

LIST OF CONFIGURATION SETTINGS				
SETTING		DEFAULT	DATE:	DATE:
1	PRESET			
1.1	UNIT	L		
1.2	DECIMALS	0		
1.3	K-FACTOR	0		
1.4	DECIMALS K-FACTOR	0		
2	OVERRUN			
2.1	TIME	0		
2.2	PRECLOSE	0		
3	METER			
3.1	SIGNAL	coil		
4	OTHER			
4.1	MODEL	BASIC61		
4.2	SOFTWARE VERSION	03.06.xx		
4.3	SERIAL NUMBER	xxxxxxx		
4.4	PIN	0000		
4.5	BACKLIGHT	off		

Your success counts



Fluidwell bv
P.O. Box 6
5460 AA Veghel
the Netherlands

Voltaweg 23
5466 AZ Veghel
the Netherlands

Website: www.fluidwell.com
Find your nearest representative: www.fluidwell.com/representatives
© Copyright 2025 - FW_B-IN-CONTROL_M_v2501-01_EN